










 6920 Salashan Pkwy, Bldg  
E-100, Ferndale, WA 98248

 1-800-281-5020

 1-780-800-3395

 info@lptentusa.com

 www.lptentusa.com

-  Make sure the zipper is undone before attaching the wall to the frame
-  Make sure the top Velcro straps are secured and the anchor points are positioned properly through the top before you fully extend the frame.
-  Do not force the frame open, if the frame is not opening smoothly look for obstructions.
-  Make sure you push in the handle then release the lock. Do not use force to release the lock. (ZP Only)
-  Make sure the locking mechanisms in the corners are released before folding the tent. (ZP Only)
-  Make sure the tent is secured with rope attached to the anchor point and staked into the ground. Adding weights is always recommended.
-  If the tent is on asphalt or concrete, attempt to find a place you can secure the tent with rope, and make sure the tent is weighted.

### Troubleshooting:

If the frame is not opening, look for possible obstructions.